

No.	Sym.	Part Description	Part Number	Unit Size
PUMP AND MOTOR ACCESSORIES (Cont)				
62		Packing Ring – Internal (All Motors)	028-07640	ES 1A1–ES 14F3
63		Gasket, Solution Pump (2x4 Suc.)	070-12519	ES 1A1–ES 7D1, ES 10E3–ES 14F3
64		Gasket, Refrigerant Pump (2x4 Suc.)	070-12519	ES 1A1–ES 9E2
65		Gasket, Solution Pump (2x4 Dis.)	067-53559	ES 1A1–ES 7D1, ES 10E3–ES 14F3
66		Gasket, Refrigerant Pump (2x4 Dis.)	067-53559	ES 1A1–ES 9E2
67		Gasket, Solution Pump (3x6 Suc.)	067-58740	ES 5C3–ES 14F3
68		Gasket, Refrigerant Pump (3x6 Suc.)	067-58740	ES 8E1–ES 14F3
69		Gasket, Solution Pump (3x6 Suc.)	067-53560	ES 5C3–ES 14F3
70		Gasket, Refrigerant Pump (3x6 Dis.)	067-53560	ES 8E1–ES 14F3
71		Gasket, Solution Pump (3x6 Dis.)	067-58740	ES 8E1–ES 14F3
72		Gasket, Refrigerant Pump (4x6 Suc.)	—	—
73		Gasket, Solution Pump (4x6 Suc.)	070-12519	ES 8E1–ES 14F3
74		Gasket, Refrigerant Pump (4x6 Dis.)	—	—
75		Gasket (Motor Coolant Suction)	067-45545	ES 1A1–ES 14F3
76		Gasket (Motor Coolant Discharge)	067-63255	ES 1A1–ES 14F3
77		Screen (Magnetic Strained Coolant Reservoir)	029-10346	ES 1A1–ES 14F3
78		Gasket (Magnetic Strainer Flange)	067-58981	ES 1A1–ES 14F3
79		Lockwasher – 5/8 Ext. Tooth (2x4 Pump)	021-12598	ES 1A1–ES 14F3
80		Lockwasher – 3/4 Ext. Tooth (3x6 and 4x9 Pump)	021-12899	ES 5C3–ES 14F3
81		Impeller Nut, 5/8–18UNF–2B, L.H. Thds.	067-66393	ES 1A1–ES 14F3
82		Impeller Nut, 3/4–16UNF–2B, L.H. Thds.	067-76213	ES 5C3–ES 14F3
83		P-80 Rubber Lubricant	044-01711	ES 1A1–ES 14F3
84	3SOL	Solenoid Valve (Motor Coolant)	025-16909	ES 1A1–ES 14F3
85		Spare Parts Kit (For 3SOL)	025-16910	ES 1A1–ES 14F3
86		Replacement Solenoid Coil (For 3SOL)	025-16911	ES 1A1–ES 14F3
87	1F,2F	Float Level Switch (Motor Coolant and Refr. Level)	024-11968	ES 1A1–ES 14F3
88		Contact Element Replacement (For 1F,2F)	024-14666	ES 1A1–ES 14F3
PURGE SYSTEM				
89		Vacuum Pump (ES50)	026-13522	ES 1A1–ES 4B4
90		Vacuum Pump (ES100)	026-14267	ES 4C1–ES 8D3
91		Vacuum Pump (ES200)	026-14579	ES 8E1–ES 14F3
92		Spare Parts Kit (For ES50)	026-14481	ES 1A1–ES 4B4
93		Spare Parts Kit (For ES100)	026-14606	ES 4C1–ES 8D3
94		Spare Parts Kit (For ES200)	026-14607	ES 8E1–ES 14F3
95		Shaft Seal Replacement Tool (For 92, 93, 94)	026-18629	ES 1A1–ES 14F3
96	6MTR	Motor (1/4 HP, 60 Hz)	024-09655	ES 1A1–ES 4B4
97	6MTR	Motor (1/4 HP, 50 Hz)	024-13310	ES 1A1–ES 4B4
98	6MTR	Motor (1/3 HP, 60 Hz)	024-09656	ES 4C1–ES 8D3
99	6MTR	Motor (1/3 HP, 50 Hz)	024-16704	ES 4C1–ES 8D3
100	6MTR	Motor (1/2 HP, 60 Hz)	024-16230	ES 8E1–ES 14F3
101	6MTR	Motor (1/2 HP, 50 Hz)	024-16229	ES 8E1–ES 14F3
102		Drive Belt (V) – 3L270	028-07714	ES 1A1–ES 4B4
103		Drive Belt (V) – 3L370	028-08676	ES 4C1–ES 8D3
104		Drive Belt (V) – 4L400	028-06090	ES 8E1–ES 14F3
105		Vacuum Hose (Pump Suction)	067-58297	ES 1A1–ES 4B4
106		Vacuum Hose (Pump Suction)	067-77988	ES 4C1–ES 8D3
107		Vacuum Hose (Pump Suction)	067-91860	ES 8E1–ES 14F3
108		Vacuum Hose (Pump Discharge)	066-29651	ES 1A1–ES 4B4
109		Vacuum Hose (Pump Discharge)	066-37304	ES 4C1–ES 8D3
110		Vacuum Hose (Pump Discharge)	066-29652	ES 8E1–ES 14F3
111		Bubble Count Bottle (Medical Vial)	028-08642	ES 1A1–ES 14F3
112		Vacuum Purge Oil (1 Gallon)	044-02028	ES 1A1–ES 14F3
113		Motor Pulley Replacement (For 96 thru 99)	028-08686	ES 1A1–ES 8D3
114		Motor Pulley Replacement (For 100 & 101)	028-08687	ES 8E1–ES 14F3
115		Belt Guard Gasket	028-09317	ES 1A1–ES 4B4