

TABLE 3— HOT WATER CONTROL VALVES

Valve Size (In.)	Pneumatic—Cast Iron		Pneumatic—Cast Iron		Pneumatic—Cast Steel	
	Fisher Valves		Honeywell Valves		Fisher	Honeywell
	125 #	250 #	125 #	250 #	300 #	300 #
1	—	—	022-03009	022-03018	—	—
1-1/4	—	—	022-03010	022-03019	—	—
1-1/2	022-04396	022-04397	022-03011	022-03020	022-04398	—
2	022-04399	022-04400	022-03012	022-03021	022-04401	—
2-1/2	022-04402	022-04403	022-03013	022-03022	022-04404	—
3	022-04405	022-04406	022-03014	022-03023	022-04407	—
4	022-04408	022-04409	022-03015	022-03024	022-04410	—
6	022-04411	022-04412	022-03016	022-03025	022-04413	—
8	—	—	022-03017	022-03026	—	—

TABLE 4— STEAM CONTROL VALVE ASSEMBLIES, ACTUATORS, AND INSTALLATION DRAWINGS

Valve Size (In.)	Valve Type	Valve Ass'y YORK Part No.	Actuator YORK Part No.	Valve Ass'y Installation Drawings	
				ESA, ESC Units	ESB, ESD Units
				3	Cage
4	Cage	022-02563	022-02821	366-52157	366-52158
5	Cage	022-02718	022-02821	366-52157	366-52158
6	Cage	022-02625	022-02821	366-52157	366-52158
4	Butterfly	022-03858	—	366-52161	366-52162
5	Butterfly	022-03859	—	366-52161	366-52162
6	Butterfly	022-03860	—	366-52161	366-52162
8	Butterfly	022-04058	—	366-52161	366-52162

TABLE 5— REFRIGERANT PUMP ISOLATION KIT

Unit Size	ESA, ESB, ESC, ESD, ESE, ESF, ESG, ESH	
	50 Hertz	60 Hertz
	1A1	366-53819
1A2	366-53819	366-53819
2A3	366-53819	366-53819
2A4	366-53819	366-53819
2B1	366-53819	366-53819
3B2	366-53819	366-53819
3B3	366-53819	366-53819
4B4	366-53819	366-53819
4C1	366-53819	366-53819
5C2	366-53819	366-53819
5C3	366-53819	366-53819
6C4	366-53819	366-53819
7D1	366-53819	366-53819
7D2	366-53819	366-53819
8D3	366-53819	366-53819
8E1	366-53820	366-53819
9E2	366-53820	366-53819
10E3	366-53820	366-53820
12F1	366-53820	366-53820
13F2	366-53820	366-53820
14F3	366-53820	366-53820

TABLE 6— SOLUTION PUMP ISOLATION KIT

Unit Size	ESA, ESC, ESE & ESG		ESB, ESD, ESF & ESH	
	50 Hertz	60 Hertz	50 Hertz	60 Hertz
	1A1	366-53809	366-53809	366-53809
1A2	366-53809	366-53809	366-53809	366-53809
2A3	366-53809	366-53809	366-53809	366-53809
2A4	366-53809	366-53809	366-53809	366-53809
2B1	366-53810	366-53810	366-53810	366-53810
3B2	366-53810	366-53810	366-53810	366-53810
3B3	366-53810	366-53810	366-53810	366-53810
4B4	366-53810	366-53810	366-53810	366-53810
4C1	366-53810	366-53810	366-53810	366-53810
5C2	366-53810	366-53810	366-53810	366-53810
5C3	366-53810	366-53810	366-53814	366-53814
6C4	366-53814	366-53810	366-53814	366-53814
7D1	366-53814	366-53810	366-53814	366-53814
7D2	366-53814	366-53814	366-53814	366-53814
8D3	366-53814	366-53814	366-53814	366-53814
8E1	366-53815	366-53817	366-53815	366-53817
9E2	366-53815	366-53817	366-53815	366-53817
10E3	—	366-53817	—	366-53817
12F1	—	366-53818	—	366-53818
13F2	—	366-53818	—	366-53818
14F3	—	366-53818	—	366-53818

TABLE 7— GENERATOR ISOLATION KIT

Unit	Hertz	Part No.
10E3	50	366-53812
12F1	50	366-53816
13F2	50	366-53816
14F3	50	366-53816

TABLE 8— ABSORBER ISOLATION KIT

Unit	Hertz	Part No.
10E3	50	366-53811
12F1	50	366-53813
13F2	50	366-53813
14F3	50	366-53813