



FIG. 3 – CONTROL CENTER – UPPER COMPARTMENT

**AUXILIARY CONTROL COMPARTMENT  
(BASIC PARTS) (REFER TO FIGS. 2 & 3)**

ITEM	DESCRIPTION	PART NO.	QUAN.	SEE FIG.
27	Cover, Auxiliary Box	066-81441	1	2
28	Label, Oil Pump	035-03950	1	2
29	Starter - Oil Pump	024-19119-002	1	3
30	Operator, Starter Overload	024-20293	1	2