



SERVICE NOTE: Pin Location 52 in Model Number will be "X" for Standard Fan, or "L" for Ultra Low Noise Fan. See page 4.

SERVICE NOTE: Fan Hub to Shaft Joint should be sealed with protective coating - factory uses RUST VETO 344 - a solvent type, rust preventative coating.

FIGURE 4 - FAN COMPONENTS - MODELS QCC2025C, 030C, 040C, 045C, 050C, 060C AND QCC2070C

TABLE 4 - FAN COMPONENTS - MODELS QCC2025C, 030C, 040C, 045C, 050C, 060C AND QCC2070C

ITEM	DESCRIPTION	VOLTAGE CODE	FAN TYPE	
			STANDARD 7/8", 1150 RPM	ULTRA LOW NOISE 7/8", 850 RPM
1 ^s	Motor, Fan 2 HP (025C, 030C, 040C, 045C, 050C, 060C & 070C)	-17	024-27322-103	024-34980-102
		-28	024-27322-106	024-34980-102
		-40	024-27322-104	024-34980-105
		-46	024-27322-207	024-34980-101
		-50	024-27322-207	024-34980-101
		-58	024-27322-102	024-34980-104
2 ^s	Blade (025C, 030C, 060C & 070C)	All	026-41594-000*	026-41942-000
	Blade (040C, 045C & 050C)		026-41592-000	026-41593-000
3	Guard (025C, 030C, 060C & 070C)	All	026-46008-000	
	Guard (040C, 045C & 050C)		026-37521-000	
4	Orifice (025C, 0035, 0065 & 0072)	All	026-45789-000	
	Orifice (0045, 045C & 050C)		026-42029-000	
5	Support, Fan	All	026-41937-000*	026-45533-000
6	Support, Ring	All	026-36367-000	
7	Spacer (.375 I.D.)	All	075-29007-000	
8	Screw, Cap (M8x125)	All	021-18494-000	
9	Spacer (1.406 I.D.)	All	075-40484-000	
10	Hub, Square	All	026-41939-001*	026-41939-005

^s = Recommended Spare Parts

***NOTE:** QCC2025C and QCC2030C, -46 & -50 voltage code units use Fan Blade 026-43090-000 and Square Hub 026-41939-002. QCC2060C and QCC2070C, -46 & -50 voltage code units use Fan Blade 026-41594-000, Fan Support 026-41938-000 and Square Hub 026-41939-005.