

TABLE 12 - R-410A COMPRESSOR PART NUMBERS (CONT'D)

MODEL	VOLTAGE CODE	SYSTEM 2 #4 COMPRESSOR		SYSTEM 2 #5 COMPRESSOR		FIGURE
		PART #	MODEL #	PART #	MODEL #	
QTC2015T	17 & 28	N/A	N/A	N/A	N/A	12
	40					
	46					
	58					
QTC2020T	17 & 28	N/A	N/A	N/A	N/A	
	40					
	46					
	58					
QTC2025T	17 & 28	N/A	N/A	N/A	N/A	
	40					
	46					
	58					
QTC2030T	17 & 28	N/A	N/A	N/A	N/A	
	40					
	46					
	58					
QTC2035T	17 & 28	015-04060-101	ZP120KCE	015-04060-101	ZP120KCE	
	40	015-04060-102		015-04060-102		
	46	015-04060-104		015-04060-104		
	58	015-04060-105		015-04060-105		
QTC2040T	17 & 28	015-04060-101	ZP120KCE	015-04060-101	ZP120KCE	
	40	015-04060-102		015-04060-102		
	46	015-04060-104		015-04060-104		
	58	015-04060-105		015-04060-105		
QTC2045T	17 & 28	015-04055-111	ZP154KCE	015-04055-111	ZP154KCE	
	40	015-04055-112		015-04055-112		
	46	015-04055-114		015-04055-114		
	58	015-04055-115		015-04055-115		

* Compressors are not interchangeable. The correct compressor must be used; substitutions are not possible. Select the proper compressor Part Number based on the compressor model on the unit.

TABLE 13 - COMPRESSOR HEATER AND COMPRESSOR SOUND BLANKET PART NUMBERS

COMPRESSOR PART NUMBER	HEATER PART NUMBER	QUANTITY PER COMPRESSOR	SOUND BLANKET PART NUMBER	QUANTITY PER COMPRESSOR	FIGURE
015-04041-xxx	025-40351-000	1	010-06507-005	1	12
015-04055-xxx	025-40351-000	1	010-06507-007	1	
015-04060-xxx	025-40351-000	1	010-06507-005	1	
015-04061-xxx	025-40351-000	1	010-06507-005	1	
015-04166-xxx	025-37888-000	1	010-06507-007	1	