

LIST OF TABLES

| | |
|---|----|
| TABLE 1 - Microchannel Condenser Coil Components - Design Series "A" | 7 |
| TABLE 2 - Condenser Coil Components - Design Series "B" | 9 |
| TABLE 3 - Fan Components | 10 |
| TABLE 4 - Refrigerant Piping Components | 12 |
| TABLE 5 - Hot Gas By-Pass Components..... | 13 |
| TABLE 6 - Compressor Part Numbers - R-410A | 15 |
| TABLE 7 - Recommended Compressor Oil Type | 17 |
| TABLE 8 - Compressor Heater and Sound Blanket Part Numbers..... | 17 |
| TABLE 9 - Compressor Components..... | 17 |
| TABLE 10 - Control Panel and Power Panel Identifiers..... | 19 |
| TABLE 11 - Power Panel Components - QCC3080C | 23 |
| TABLE 12 - Power Panel Components - QCC3085C | 24 |
| TABLE 13 - Power Panel Components - QCC3090C | 25 |
| TABLE 14 - Power Panel Components - QCC3100C | 26 |
| TABLE 15 - Power Panel Components - QCC3130C | 27 |
| TABLE 16 - Power Panel Components - QCC3145C | 28 |
| TABLE 17 - Power Panel Components - QCC3160C | 29 |
| TABLE 18 - Control Panel Components | 33 |
| TABLE 19 - Sensor Harness Wiring - QCC3080C, 085C, 090C, 110C, 145C and QCC3160C | 36 |
| TABLE 20 - Sensor Harness Wiring - QCC3100C and QCC3130C | 36 |
| TABLE 21 - Transducers, Pressure Cutouts and Temp Sensors | 37 |
| TABLE 22 - Transducer And Thermistor Wire Harness Connectors - Field Replacement Part Numbers..... | 38 |
| TABLE 23 - Vibration Isolators Part Numbers..... | 39 |
| TABLE 24 - Field Installed Options Part Numbers..... | 40 |
| TABLE 25 - Control Transformer Kit | 40 |
| TABLE 26 - Enclosure Kit Options | 41 |
| TABLE 27 - Wire Enclosure | 42 |
| TABLE 28 - Louvered Enclosure..... | 43 |
| TABLE 29 - Remote Control Center Parts - 371-02485-104 (60Hz)..... | 44 |
| TABLE 30 - Recommended Spare Parts - QCC3080C-QCC3160C Chillers..... | 45 |

WARNING

HIGH VOLTAGE

Is used in the operation of this equipment.

DEATH OR SERIOUS INJURY

may result if personnel fail to observe safety precautions.

Work on electronic equipment should not be undertaken unless the individual(s) have been trained in the proper maintenance of equipment and is (are) familiar with its potential hazards.

Shut off power supply to the equipment before beginning work and follow lockout procedures. When working inside equipment with power off, take care to discharge every capacitor likely to hold dangerous potential.

Be careful not to contact high voltage connections when installing or operating this equipment.

LOW VOLTAGE

DO NOT be misled by the term "low voltage." Voltages as low as 50 volts may cause death.