



Item no.	Part no.	Description
2-6	R310-1525*	Heater Cable
3-7	11-4946-1	End Shutter
3-8	11-4945-3	Middle Shutter
3-9	11-4949-1	End Shutter Shaft
3-10	11-4948-1	Middle Shutter Shaft
4-7	1486A-0	Pilot Solenoid Gas Valve, 3/4"
4-8	8699-01-213	Balancing Orifice, 1/2"
4-9	7347-0-A	Pilot Gas Regulator, 3/4"
4-10	R300-6292	Pilot Jet Gas Gauge, 0-15 psi (Steel) or
	8735-Q	Pilot Jet Gas Gauge, 0-5 psi (Brass)
4-11	R930-6022	Gauge Needle Valve, 1/4" (Steel) or
	1836-03	Gauge Needle Valve, 1/4" (Brass)
5-7	R310-1510	Heating Tape (included in 11-5292-2 Atomizer Assembly)
5-9	R914-5702	Oil Tube (included in 11-5292-2 Atomizer Assembly)
5-10	1821A-0	Ball Valve, 3/4" (included in 11-5292-2 and 11-5292-1 Atomizer Assembly)
30	1517U-1-CR5	1" Automatic Shutoff Oil Valve 50 Hz or
	1517U-1-CR6	1" Automatic Shutoff Oil Valve 60 Hz
34	R620-2060	Fisher Positioner
34-3	1600-P	Moore Positioner (not actually pictured but location shown)

\* Should be wrapped with R290-1194 Tetraglas tape 1 1/2" W x 1/8" thick with adhesive backing.

**WARNING:** Situations dangerous to personnel and property may exist with the operation and maintenance of any combustion equipment. The presence of fuels, oxidants, hot and cold combustion products, hot surfaces, electrical power in control and ignition circuits, etc., are inherent with any combustion application. Components in combustion systems may exceed 160°F (71°C) surface temperatures and present hot surface contact hazard. Fives North American Combustion, Inc. suggests the use of combustion systems that are in compliance with all Safety Codes, Standards, Regulations and Directives; and care in operation.